

The FinFly USB provides an easy-to-use and reliable way of installing Remote Monitoring Solutions on computer systems when physical access is available.

Once the FinFly USB is inserted into a computer, it **automatically installs the configured software** with little or no user-interaction and **does not require IT-trained Agents** when being used in operations. The FinFly USB can be used against **multiple systems** before being returned to Headquarters.

Usage Example 1: Technical Surveillance Unit

The FinFly USB was successfully used by **Technical Surveillance Units** in several countries to deploy a Remote Monitoring Solution onto Target Systems that were switched off, by simply **booting the system from the FinFly USB device**. This technique worked even for Target Systems that had **full hard-disk encryption** with products like TrueCrypt enabled.

QUICK INFORMATION	
Usage:	· Tactical Operations
Capabilities:	· Deploys Remote Monitoring Solution on Target
Content:	· Hardware

Usage Example 2: Intelligence Agency

A Source in a domestic terror group was given a FinFly USB that **secretly installed a Remote Monitoring Solution** on several computers of the group when they were using the device to exchange documents between each other. The Target Systems could then be **remotely monitored from Headquarters**, and the FinFly USB was later returned by the Source.

Feature Overview

- Can deploy even on **powered off systems with full hard-disk encryption** (e.g. TrueCrypt)
- **Covertly installs Remote Monitoring Solution** on insertion in Target System
- **Little or no user-interaction** is required
- Functionality can be **concealed by placing regular files** like music, video and office documents on the device
- Hardware is a **common and non-suspicious USB device**

For a full feature list, please refer to the Product Specifications.




Product Components



FinFly USBs

- USB Dongle
- Deploys a Remote Monitoring Solution on Insertion into Target Systems
- Deploys Remote Monitoring Solution during Boot Process



Full FinSpy Integration

- Automatic generation and activation through FinSpy Agent